

The **YES** Company!!

SUPERCO
SPECIALTY
PRODUCTS

SUPER-KOTE
ACRYLIC FLOOR AND PATIO PAINT

- PROVIDES EXCELLENT WEAR IN EXTREMELY HIGH TRAFFIC AREAS.
- MAY BE ROLLED, BRUSHED OR SPRAYED ON.
- UP TO 400 SQUARE FEET PER GALLON ON A SMOOTH SURFACE AND BETWEEN 100-300 SQUARE FEET ON A ROUGH SURFACE.

"GRIT" ADDITIVE AVAILABLE FOR NON-SLIP SURFACE

PRODUCT #7044

FOR PROFESSIONAL USE ONLY
CONSULT LABEL AND MSDS BEFORE USING.

Choose from 11 different colors:

- ADOBE • BLACK • CLEAR
- DESERT GOLD • DESERT GRAY
- FOREST GREEN • MAHOGANY
- METAL GRAY • RUSTIC RED
- SONORA TAN • WHITE

SUPER-KOTE is ideal for concrete, patios, pavement, terrazzo surfaces, asphalt, driveways, factory floors, and wood decks.. **SUPER-KOTE** is an acrylic low sheen, smooth or textured coating, that forms a very tough finish for all porous exterior or interior floor surfaces. It has an outstanding durability, its chemical and abrasive resistance assures excellent wear in extremely heavy traffic areas. It is highly resistant to "hot tire pickup", sunlight and moisture. **SUPER-KOTE** is free of lead and pollution free. When mixed with non-skid additive **GRIT**, **SUPER-KOTE** is a non-skid surface. **SUPER-KOTE** is for porous and properly prepared surfaces only.

1	HEALTH
1	FLAMMABILITY
0	REACTIVITY
	PROTECTION

INGREDIENTS	CAS #
ACRYLIC POLYMERS SOLIDS	28377-44-8
ETHYLENE GLYCOL	111-76-2
WATER	7732-18-5

PREPARING CONCRETE FLOORS FOR PAINTING

Before You Get Started: Read product labels and MSDS information. Be familiar with what you will be using. Use appropriate safety gear and good common sense.

Work area should be well ventilated at all times.

Step 1. Use **SUPER-STRIP** to remove old paint. Apply paint stripper liberally and spread-out to cover painted area with broom, roller, or brush. Allow to work for 15 to 20 minutes, or until blistering action is complete. DO NOT allow stripper to dry on surface. The use of a deck brush may speedup removal of old paint. Mop or rinse old paint and stripper and continue applying more **SUPER-STRIP** until all paint is removed from the floor.

Step 2. Make sure all oil stains have been cleaned with **HURRICANE 5** to 1 dilution..

Step 3. Inspect floor, if surface is really smooth you must etch concrete with **DE-SCALE**. Use **SUPERCO DE-SCALE** concrete etching

compound to prepare floor for sealing. Apply compound liberally, spreading with nylon deck brush or Hudson type sprayer, and allow to work for approximately 5 minutes. DO NOT allow to dry on surface. Rinse thoroughly with water and squeegee. Allow floor to dry. We recommend continuous ventilation to insure a clean, dry, surface.

Step 4. Use **HURRICANE** cleaner mixed with 5 parts water to thoroughly clean any excess **DE-SCALE** and to neutralize pH. Rinse and squeegee floor thoroughly.

Step 5. Apply **SUPER-KOTE** by using a good quality roller or brush. Synthetic bristle brushes are recommended. **SUPER-KOTE** may be rolled, brushed or sprayed. Avoid painting in direct sunlight as this causes rapid dry and retards adhesion. Thinning slightly with water and applying thin coats will help avoid streaks in direct sunlight. For added skid resistance on smooth surfaces, add **SUPERCO GRIT** non-skid additive as needed to the first coat of **SUPER-KOTE**. For proper drying time allow four hours for light foot traffic. Normal foot traffic after 24 hours. Allow 48 hours before placing heavy objects on the surface.